


SERVICE MANUAL
PRICE \$5.00

Velvet Drive Marine Transmission
Service Manual Model: 73C
Direct Drive and 1.5:1, 2.0:1, 3.0:1
Reduction Ratios



Borg-Warner
Automotive,
Inc.

Transmission
Systems

Post Office
Box 2688

Muncie
Indiana
47307

Telephone
317 286 6100
Telex
27 491



BorgWarner
Automotive

TABLE OF CONTENTS

| | |
|--|----|
| DESCRIPTION | 4 |
| OPERATION | 5 |
| HYDRAULIC CIRCUITS | 5 |
| HYDRAULIC CIRCUIT SCHEMATIC DRAWING | 6 |
| INSTALLATION RECOMMENDATIONS | 7 |
| INSTALLATION DIMENSIONS MODEL 73C REDUCTIONS | 8 |
| INSTALLATION DIMENSIONS MODEL 73C DIRECT DRIVE | 9 |
| AS1-73C DIRECT DRIVE PARTS LIST | 11 |
| AS2-73C 1.50:1 PARTS LIST | 13 |
| AS7-73C 2.00:1 PARTS LIST | 15 |
| AS5-73C 3.00:1 PARTS LIST | 17 |
| PARTS INTERCHANGEABILITY | 18 |
| REPAIR KITS FOR MODEL 73C | 19 |
| DISASSEMBLY OF TRANSMISSION | 20 |
| DISASSEMBLY OF REDUCTION UNITS | 21 |
| ASSEMBLY OF TRANSMISSION | 23 |
| ASSEMBLY OF TRANSMISSION WITH REDUCTION UNIT | 25 |
| SERVICE PRECAUTIONS AND INSTRUCTIONS | 27 |
| PINION CAGE SERVICE | 28 |
| TROUBLE ANALYSIS CHART | 30 |
| TORQUE SPECIFICATIONS | 31 |
| SPECIFICATIONS SUMMARY | 31 |
| TRANSMISSION FLUID & LUBRICATION REQUIREMENTS | 31 |

DESCRIPTION

The model 73C transmission described in this manual consists of a forward and reverse gear box, which may or may not have any one of three reduction ratios, contained in a separate housing and attached to the rear face of the transmission. Input and output shafts are all coaxial and splined at their outer ends.

The forward and reverse transmission consists of a planetary gearset, a forward clutch, a reverse clutch, an oil pump, and a pressure regulator and rotary control valve, all contained in a cast iron housing. The forward clutch locks the input to the output shaft for direct drive (1.00 to 1.00 ratio), when the selector valve is in the forward position. Reverse is obtained by placing selector valve in reverse position. The selector valve directs the hydraulic oil to the reverse clutch which causes a reverse ratio of .88 to 1.00 in a reverse rotation from input shaft.

A crescent type gear pump supplies oil from the sump to the pressure regulator valve which regulates the oil for clutch operation and the excess oil is dumped to supply oil for cooler and lubrication needs. Two ball check valves and springs maintain cooler and lube pressure and the excess oil is returned to pump suction.

Three reduction ratios (3.00 to 1.00, 2.00 to 1.00 and 1.50 to 1.00) may be used in conjunction with the forward and reverse transmission. Reduction units are always engaged and have the same reduction in forward and reverse; how-

ever, the over all reverse ratio is different from forward ratio due to the ratio difference of the forward and reverse transmission.

LOCATION OF SEVERAL TRANSMISSION DETAILS ARE SHOWN IN FIGURES 1 AND 2 AS FOLLOWS:

- A. Shift Lever
- B. To Cooler Outlet
- C. Cooler Return Outlet
- D. Reverse Clutch Pressure Tap
- E. Mounting Bolt Holes
- F. Drain Plug
- G. Filler Plug & Dipstick Assembly
- H. Forward Clutch Pressure Tap
- I. Breather
- J. Input Shaft
- K. Pump
- L. Coupling
- M. Reduction Housing
- N. Adapter
- O. Lube Pressure Tap
- P. Line Pressure Tap




FIG. 1 LEFT SIDE VIEW OF TRANSMISSION.




FIG. 2 RIGHT SIDE VIEW OF TRANSMISSION.

OPERATION

STARTING ENGINE

Place transmission selector in neutral before starting engine. Shifts from any selector position to any other selector position may be made at any time and in any order if the engine speed is below 1000 RPM; it is recommended that all shifts be made at the lowest feasible engine speed.

NEUTRAL

Move the shift lever to the center position where the spring loaded ball enters the chamfered hole in the side of the shift lever and properly locates lever in neutral position, Fig. 4. With shift lever so positioned, flow of oil to clutches is blocked at the control valve. The clutches are exhausted by a portion of the valve and complete interruption of power transmission is insured.

FORWARD

Move the shift lever to the extreme forward position where the spring loaded ball enters the chamfered hole in the side of the shift lever and properly locates

lever in forward position, Fig. 4. The input and output shafts are locked together by the forward clutch and 1.00 to 1.00 ratio is obtained for forward operation.

REVERSE

Move transmission shift lever to the extreme rearward position where the spring loaded ball enters the chamfered hole in the side of the shift lever and properly locates it in the reverse position, Fig. 4. Fluid directed by the shift valve applies the reverse clutch and causes the clutch plates to hold the ring gear. The planet carrier and input shaft, turning at engine speed, drives the pinion shafts and cause the pinions to rotate about the shafts inside the ring gear. As the pinions rotate they force the sun gear and output shaft to rotate in reverse rotation and at an input to output shaft ratio of .88 to 1.00.

HYDRAULIC CIRCUITS

The transmission case is used as a sump for transmission fluid. Fluid leaving sump passes through an oil strainer and into case passages, which direct fluid to inlet side of pump. Fluid leaving pump under pressure goes directly to the rotary shift valve and regulator valve. The regulator valve, set to open at 120 PSI (827 k Pa) dumps excess fluid to maintain correct line pressure.

Fluid dumped by regulator valve, passes through case passages, flows from transmission through an externally mounted oil cooler and suitable connecting lines and is returned to transmission lube circuit. A ball check valve, ahead of cooler and set to open at 65 PSI (448 k Pa), opens if pressure to cooler becomes excessive, and dumps excess fluid to the lube circuit without going through the cooler. The AS7-73C reduction carrier has cooler pressure feed to its lube circuit.

A ball check valve, set to open at 10 PSI (70 k Pa), maintains correct lube pressure to all transmission


components, and returns excess fluid to suction side of pump. **This check valve has been removed.**

Positioning the rotary shift valve in forward (F) position directs fluid from pump, through the valve and case passages through output shaft passage and into forward clutch cylinder behind clutch piston to apply against clutch plates.

Positioning the shift valve in reverse (R) position directs fluid from pump through the valve and case passages and into adapter passage into the clutch cylinder behind reverse clutch piston, forcing piston to apply against reverse clutch plates.

Hydraulic circuits of the AS7-73C transmission shows cooler oil directed to lube the reduction carrier assembly. Hydraulic circuits of the AS2-73C transmission are similar to circuits of the AS5-73C transmissions.

THIS VALVE IS NO LONGER USED



110 PSI = 758 k Pa
130 PSI = 896 k Pa
160 PSI = 1103 k Pa

FIG. 3 HYDRAULIC CIRCUIT SCHEMATIC DRAWING.

INSTALLATION RECOMMENDATIONS

TRANSMISSION TO ENGINE ADAPTER ALIGNMENT

The adapter bore and face alignment with respect to the crankshaft preferably should be held within a total indicator reading of .005 inch (.13 mm). More than .10 inch (.25 mm) misalignment should not be accepted.

COUPLING ALIGNMENT

Propeller shaft coupling to transmission coupling alignment should be checked on all new installations after the boat has been placed in the water. Alignment should be checked after storage or trailering to insure against misalignment caused by engine shifting.

Remove coupling bolts to check alignment. Hand hold couplings to engage snap fit and make face contact at one point, then check to determine the maximum clearance between couplings at other points. Check for bent shafts or couplings by rotating each coupling and checking clearance in several different positions. The coupling faces should be within .003 inch (.07 mm) of parallel in all positions.

CONTROL LEVER

Controls for shifting the transmission should be designed to position the transmission shift lever so that the poppet ball is fully engaged in the hole in the side of the shift lever in each selector position. The selector should always be located in the forward position when the boat moves forward. Transmissions which drive the boat forward when reverse is selected are apt to fail at an early date and for this reason, no warranty claims will be allowed for failures caused by this condition.

The warranty is cancelled if the shift lever poppet spring and/or ball is permanently removed, or if linkage between remote control and transmission shift lever does not have sufficient travel in both directions.

OIL COOLER

WARNING: Do not operate the engine unless a suitable oil cooler is properly connected to the transmission. Cooler should maintain the desired 140° to 190°F. (60-88c) transmission operating temperature. Oil from cooler out (see Fig. 2) should be connected to either of the two cooler return locations.

NOTE: All transmissions are currently shipped with plastic plugs installed in transmission cooler outlet and inlet locations to identify these openings.

Maximum heat transfer will occur when water and oil flow in opposite directions through cooler.

HYDRAULIC FLUID RECOMMENDATIONS

Dexron® II, Type F, and other hydraulic transmission fluids which meet the Detroit Diesel Allison Type C3 specifications are recommended for use in all Velvet Drive® marine transmissions.

Lubricating oils which are recommended for use in diesel engines and also meet the Detroit Allison Type C3 specifications may be used if the engine speed does not exceed 3000 RPM. SAE #30 is preferred. SAE #40 is acceptable if high operating temperatures are to be encountered. Multiviscosity oils such as 10W-40 are not acceptable. The first choice is an oil which falls in the SAE-API service Class "CD." The second choice would be an oil which falls in the SAE-API Class "CC."

The equivalent DOD mil specs are:

"CD" Mil-L-2104B

"CC" Mil-L-45199

The new C3 specifications were developed by Detroit Diesel Division of General Motors to outline the requirements of an oil suitable for use in their heavy duty hydraulic automatic and powershift transmissions. The oil companies should be able to provide information as to the suitability of their product for use in a given application.

PUMP ROTATION

Determine engine rotation and purchase a transmission having pump indexed to match engine rotation; however, always check to make certain that pump is correctly indexed before installing the transmission. All Model 73C transmissions may have pump indexed for opposite rotation by removing the four pump to adapter bolts and without removing the pump, tap pump with a plastic hammer and rotate until the letters and arrow representing opposite rotation is nearest the top of pump with the four bolt holes aligned with holes in the adapter. Replace and torque the four pump bolts.




FIG. 4 INSTALLATION DIMENSIONS FOR MODEL 73C REDUCTIONS.





FIG. 5 INSTALLATION DIMENSIONS FOR MODEL 73C DIRECT DRIVES.




73C DIRECT DRIVE TRANSMISSION

DIRECT DRIVE PARTS LIST FOR MODELS: 10-06-000-004 OR AS1-73C AND 10-06-000-005 OR AS1-73CR

| INDEX NO. | W.G. PART NO. | DESCRIPTION | NO. REQ'D. | INDEX NO. | W.G. PART NO. | DESCRIPTION | NO. REQ'D. |
|-----------|-------------------|---|------------|-----------|--------------------|--|------------|
| 1 | 4775T | Main shaft nut | 1 | 53 | 73C-A12A | Bearing sleeve & bushing assembly (includes item 52) | 1 |
| 2 | 4914A | Coupling | 1 | 54 | 73C-1A2F (9) | Output shaft & sleeve assembly (includes item 53) | 1 |
| 3 | 10-00-044-017 (1) | Oil seal | 1 | 55 | 12-A66 (6) | Clutch inner plate assembly | 6 |
| 4 | 0000179860 | 7/16-14 x 1-1/4 Hex head bolt | 6 | 56 | 3-65 (7) | Clutch plate | 6 |
| 5 | 0000103322 | 7/16 Lockwasher | 6 | 57 | 5L-67 | Clutch pressure plate | 1 |
| 6 | 71-4 | Valve cover | 1 | 58 | 4751 | Snap ring | 1 |
| 7 | 73C-7 | Bearing Retainer | 1 | 59 | 4830D (10) | Needle bearing | 2 |
| 8 | 73C-146 | Case rear gasket | 1 | 60 | 4832B (11) | Thrust bearing race | 2 |
| 9 | 3-34 | "O" ring | 1 | 61 | 4840R | Needle bearing | 1 |
| 10 | 4923G | Bearing Cup | 2 | 62 | 73C-1A16E (12) | Input shaft & planet carrier assembly | 1 |
| 11 | 4922G | Bearing cone | 2 | 63 | 4897A (13) | Pump drive key | 1 |
| 12 | 73C-75 | Bearing spacer | 1 | 64 | 4806A | Sealing ring | 1 |
| 13 | 47768B | 7/16-14 x 7/8 Hex head bolt | 2 | 65 | 73C-6 | Ring gear | 1 |
| 14 | 73C-51 | Lube line cover | 1 | 66 | 4832A | Needle bearing thrust race | 1 |
| 15 | 0000444854 | 1/8 Pipe plug | 1 | 67 | Not serviced | Ring gear hub bushing (order assy.) | 1 |
| 16 | 4740A | Breather assembly-early type | 1 | 68 | 73C-A106A (14) | Ring gear hub & assembly (includes item 67) | 1 |
| | 4740G | Breather assembly-pressure type | 1 | 69 | 73C-15 | Ring gear hub thrust washer | 1 |
| 17 | 0000444864 | 3/8 Pipe plug | 1 | 70 | 4822A | Ring gear snap ring | 1 |
| 18 | 0000444864 | 3/8 Pipe plug | 1 | 71 | 73C-71 | Reverse clutch pressure plate | 2 |
| 19 | 71-2A195 | Dipstick assembly-screw-in type | 1 | 72 | 71-97 | Pressure plate spring | 12 |
| N.I. | 10-06-559-001 | Dipstick assembly-latest type | 1 | 73 | 10-17-666-001 | Reverse clutch plate, inner | 4 |
| N.I. | 10-04-034-002 | Dipstick tube | 1 | 74 | 72-176 | Reverse clutch plate, outer | 3 |
| 20 | 71-42 | Poppet spring | 1 | 75 | 4622F | Dowel pin | 3 |
| 21 | 0000453632 | 5/16 Steel ball | 1 | 76 | 4805A | Sealing ring | 1 |
| 22 | 68C-79 | Forward & reverse shift lever | 1 | 77 | 71-35 | Reverse clutch piston | 1 |
| 23 | 0000103340 | Control lever washer | 1 | 78 | 4804G | Sealing ring | 1 |
| 24 | 0000108579 | 5/16 Lockwasher | 1 | 79 | 73C-144 | Case & adapter gasket | 1 |
| 25 | 0000115729 | 5/16-24 Hex nut | 1 | 80 | 4840T | Needle bearing | 1 |
| 26 | 0000453595 | 7/16 Steel ball | 2 | 81 | 0000444854 | 1/8 Pipe plug | 3 |
| 27 | 72M-273 | Cooler check valve spring | 1 | 82 | 0000444858 | 1/4 Pipe plug | 1 |
| 28 | 68C-269 | Check valve spring | 1 | 83 | 73C-A8 | Trans. adapter & brg. assembly | 1 |
| 29 | 10-06-565-001 (2) | Forward & reverse trans. case & plug assembly | 1 | 84 | 4911 | 3/8-16 x 1-1/4 Capscrew | 4 |
| 30 | 73C-140 | Oil baffle | 1 | N.I. | 71C-A60 | Pump ass'y. (items 85,86,88 & 89) | 1 |
| 31 | 4652KK | bearing spacer | 1 | 85 | Not serviced | Pump drive gear (order assembly) | 1 |
| 32 | 4806R | Sealing ring | 2 | 86 | Not serviced | Pump driven gear (order assembly) | 1 |
| 33 | 73C-50A (4) | Direct clutch cylinder | 1 | 87 | 3-61 | Pump gasket | 1 |
| 34 | 4559A | Snap ring | 1 | 88 | Not serviced | Pump housing (order assembly) | 1 |
| 35 | 3-46 | Sealing ring | 1 | 89 | 10-00-044-014 (15) | Oil seal assembly | 1 |
| 36 | 6-A45 (5) | Clutch piston & ball assembly | 1 | 90 | 0000179822 | 5/16-18 x 1-1/2 Hex head bolt | 4 |
| 37 | 10-00-113-007 | Plug | 1 | N.I. | 10-00-183-021 (16) | 5/16-18 x 1-3/8 Hex head bolt | 4 |
| 37A | 4572N | Plug | 1 | 91 | 68C-268 | Check valve spring retainer | 2 |
| 38 | 71-246 | Valve spring retainer | 1 | N.I. | 4636KR | Service name plate | 1 |
| 39 | 71-14 | Valve cover gasket | 1 | N.I. | 000145366 | Drive screw | 2 |
| 40 | 0000103319 | 1/4 Lockwasher | 3 | N.I. | 10-16-039-001 | Valve cover | 1 |
| 41 | 0000179793 | 1/4-20 x 5/8 Hex head bolt | 3 | N.I. | 10-00-640-004 | Switch & "O" ring assembly | 1 |
| | 0000179791 | 1/4-20 x 1-1/2 Hex head bolt | 1 | N.I. | 10-00-141-006 | "O" Ring | 1 |
| 42 | 4821 | Snap ring | 1 | N.I. | 10-16-099-001 | Switch cam | 1 |
| 43 | 5G-246 | Valve spring | 1 | N.I. | 0000179796 | Hex HD bolt | 3 |
| 44 | 73C-243 | Pressure regulator valve | 1 | | | | |
| 45 | 73C-244 | Forward & reverse gear trans. valve | 1 | | | | |
| N.I. | 73C-A244 (8) | Valve assembly (Items 42,43,44,45) | 1 | | | | |
| 46 | 4804H | "O" Ring | 1 | | | | |
| 47 | 0000444864 | 3/8 Pipe plug | 2 | | | | |
| 48 | 0000444592 | 3/4 Pipe plug | 1 | | | | |
| 49 | 71C-A98A | Oil strainer assembly | 1 | | | | |
| 50 | 3-47A | Clutch spring | 1 | | | | |
| 51 | 3-44 | Sealing ring | 1 | | | | |
| 52 | Not serviced | Bearing sleeve bushing (order assy.) | 1 | | | | |

NOTES 1-15: SEE PAGE 18
N.I. - NOT ILLUSTRATED




73C TRANSMISSION WITH 1.50:1 REDUCTION DRIVE

1.50:1 REDUCTION UNIT PARTS LIST FOR MODELS: 10-06-000-006 OR AS2-73C AND 10-06-000-007 OR AS2-73CR

| INDEX NO. | W.G. PART NO. | DESCRIPTION | NO. REQ'D. | INDEX NO. | W.G. PART NO. | DESCRIPTION | NO. REQ'D. |
|-----------|-------------------|---------------------------------------|------------|-----------|--------------------|--|------------|
| 1 | 0000179860 | 7/16-14 x 1-1/4 Hex head bolt | 6 | 69 | 0000103319 | 1/4 Lockwasher | 3 |
| 2 | 0000103322 | 7/16 Lockwasher | 6 | 70 | 71-4 | Valve cover | 1 |
| 3 | L14-1 | Reduction unit housing | 1 | 71 | 71-14 | Valve cover gasket | 1 |
| 4 | 73C-146 | Case rear gasket | 1 | N.I. | 73C-A244 (8) | Valve & spring ass'y. (Items 72, 73, 74, 75 & 76) | 1 |
| 5 | L14-4 | Reduction sun gear | 1 | 72 | 4821 | Snap ring | 1 |
| 6 | L14-140 | Reduction oil baffle | 1 | 73 | 71-246 | Valve spring retainer | 1 |
| 7 | 4776BB | 7/16-14 x 7/8 Hex lock bolt | 5 | 74 | 5G-246 | Valve spring | 1 |
| 8 | 4765B | Snap ring | 1 | 75 | 73C-243 | Pressure regulator valve | 1 |
| 9 | L14-A150 | Pinion cage assembly | 1 | 76 | 73C-244 | Forward & reverse gear trans. valve | 1 |
| 10 | L14-2 | Reduction output shaft | 1 | 77 | 4804H | "O" Ring | 1 |
| 15 | 4765B | Snap ring | 1 | 78 | 0000444864 | 3/8 Pipe plug | 1 |
| 16 | 73C-6 | Reduction ring gear | 1 | 79 | 0000444592 | 3/4 Pipe plug | 1 |
| 17 | 4746 | Snap ring | 1 | 80 | 71C-A98A | Oil strainer assembly | 1 |
| 18 | L14-16 | Reduction ring gear hub | 1 | 81 | 73C-1A2E (9) | Output shaft & sleeve assembly | 1 |
| 19 | 0000179857 | 7/16-14 x 7/8 Hex head bolt | 6 | 82 | 4830D (10) | Needle bearing | 1 |
| 20 | 4822A | Ring gear snap ring | 1 | 83 | 4832B (11) | Thrust bearing race | 1 |
| 21 | 0000115550 | 7/16 Lockwasher | 6 | 84 | 4840R | Needle bearing | 1 |
| 22 | L14-8 | Bearing retainer | 1 | 85 | 73C-1A16E (12) | Input shaft & planet carrier ass'y. | 1 |
| 23 | 4745E | Bearing snap ring | 1 | 86 | 4897A (13) | Pump drive key | 1 |
| 24 | 4775T | Main shaft nut | 1 | 87 | 73C-6 | Ring gear | 1 |
| 25 | 4914 | Coupling | 1 | 88 | 4832A | Needle thrust bearing race | 1 |
| 26 | 10-00-044-017 (1) | Oil seal | 1 | 89 | 4830D | Needle bearing | 1 |
| 27 | L14-7 | Bearing retainer | 1 | 90 | 4832B | Thrust bearing race | 1 |
| 28 | 73C-147 | Bearing retainer gasket | 1 | 91 | Not serviced | Ring gear hub bushing | 1 |
| 29 | 4920B | Bearing | 1 | 92 | 73C-A106A (14) | Ring gear hub & bushing assembly | 1 |
| 30 | 0000179861 | 7/16-14 x 1-3/8 Hex head bolt | 6 | 93 | 71C-15 | Ring gear hub thrust washer | 1 |
| 31 | 0000103322 | 7/16 Lockwasher | 6 | 94 | 4822A | Ring gear snap ring | 1 |
| 32 | B308AG | Bearing | 1 | 95 | 73C-71 | Reverse clutch pressure plate | 1 |
| 33 | 4804R | "O" Ring | 1 | 96 | 71-97 | Pressure plate spring | 2 |
| 35 | 10-00-113-007 | Plug | 1 | 97 | 10-17-666-001 | Reverse clutch plate, inner | 4 |
| 36 | 4740A | Breather assembly-early type | 1 | 98 | 72-176 | Reverse clutch plate, outer | 3 |
| | 4740G | Breather assembly-pressure type | 1 | 99 | 73C-71 | Reverse clutch pressure plate | 1 |
| 38 | 0000444854 | 1/8 Pipe plug | 1 | 100 | 4822F | Dowel pin | 3 |
| 39 | 0000444864 | 3/8 Pipe plug | 1 | 101 | 4840T | Needle bearing | 1 |
| 40 | 71-2A195 | Dipstick assembly-screw-in type | 1 | 102 | 4805A | Sealing ring | 1 |
| N.I. | 10-06-559-001 | Dipstick assembly-new type | 1 | 103 | 71-35 | Reverse clutch piston | 1 |
| N.I. | 10-04-034-002 | Dipstick tube | 1 | 104 | 4806A | Sealing ring | 1 |
| 41 | 71-42 | Poppet spring | 1 | 105 | 4804G | Sealing ring | 1 |
| 42 | 0000453632 | 5/16 Steel ball | 1 | 106 | 0000444858 | 1/4 Pipe plug | 1 |
| 43 | 68C-79 | Forward & reverse shift lever | 1 | 107 | 0000444854 | 1/8 Pipe plug | 1 |
| 44 | 0000115729 | 5/16-24 Hex nut | 1 | 108 | 73C-A8 | Trans. adapter & bearing assembly | 1 |
| 45 | 0000108579 | 5/16 Lockwasher | 1 | N.I. | 71C-A60 | Pump assembly (Items 109, 110, 112 & 113) | 1 |
| 46 | 0000103340 | Control lever washer | 1 | 109 | Not serviced | Pump drive gear (order assembly) | 1 |
| 47 | 0000453595 (17) | 7/16 Steel ball | 1 | 110 | Not serviced | Pump driven gear (order ass'y.) | 1 |
| 48 | 72M-273 (17) | Cooler check valve spring | 1 | 111 | 3-61 | Pump gasket | 1 |
| 49 | 68C-268 (17) | Check valve spring retainer | 1 | 112 | Not serviced | Pump housing (order assembly) | 1 |
| 50 | 68C-269 | Check valve spring | 1 | 113 | 10-00-044-014 (15) | Oil seal assembly | 1 |
| 51 | 10-06-565-001 (2) | Forward & reverse transmisson case | 1 | 114 | 0000179822 | 5/16-18 x 1-1/2 hex head bolt | 4 |
| 52 | 73C-140 | Oil baffle | 1 | N.I. | 10-00-183-021 (16) | 5/16-18 x 1-3/8 Hex head bolt | 4 |
| 53 | 73C-52A (3) | "O" Ring backing plate | 2 | 115 | 73C-144 | Case & adapter gasket | 1 |
| 54 | 3-34 | "O" Ring | 1 | N.I. | 4636KR | Name plate, for service | 1 |
| 55 | 4806R | Sealing ring | 2 | N.I. | 0000145366 | Drive screw | 2 |
| 56 | 73C-50A (4) | Direct clutch cylinder | 1 | 116 | 4911 | 3/8)16 x 1-1/4 | 4 |
| 57 | 4559A | Snap ring | 1 | | | | |
| 58 | 3-46 | Sealing ring | 1 | | | | |
| 59 | 6-A45 (5) | Clutch piston & ball assembly | 1 | | | | |
| 60 | 3-65 (6) | Clutch plate (steel) | 6 | | | | |
| 61 | 12-A66 (7) | Clutch inner plate assembly | 6 | | | | |
| 62 | 5L-67 | Clutch pressure plate | 1 | | | | |
| 63 | 4751 | Snap ring | 1 | | | | |
| 64 | 3-47A | Clutch spring | 1 | | | | |
| 65 | 3-44 | Sealing ring | 1 | | | | |
| 66 | Not serviced | Bearing sleeve bushing (order ass'y.) | 1 | | | | |
| 67 | 73C-A12A | Bearing sleeve & bushing assembly | 1 | | | | |
| 68 | 0000179793 | 1/4-20 x 5/8 Hex head bolt | 3 | | | | |
| | 0000179791 | 1/4-20 x 1/2 Hex head bolt | 3 | | | | |

NOTES 1-15: SEE PAGE 18

N.I. - NOT ILLUSTRATED




73C TRANSMISSION WITH 2.00:1 REDUCTION DRIVE

2.00:1 REDUCTION UNIT PARTS LIST FOR MODELS: 10-06-000-010 OR AS7-73C AND 10-06-000-011 OR AS7-73CR

| INDEX NO. | W.G. PART NO. | DESCRIPTION | NO. REQ'D | INDEX NO. | W.G. PART NO. | DESCRIPTION | NO. REQ'D |
|-----------|-------------------|---------------------------------------|-----------|-----------|--------------------|--|-----------|
| 1 | 0000179860 | 7/16-14 x 1-1/4 Hex head bolt | 6 | 67 | 72C-A12A | Bearing sleeve & bushing assembly | 1 |
| 2 | 0000103322 | 7/16 Lockwasher | 6 | 68 | 0000179793 | 1/4-20 x 5/8 Hex head bolt | 3 |
| 3 | L14-1 | Reduction unit housing | 1 | | 0000179791 | 1/4-20 x 1/2 Hex head bolt | 3 |
| 4 | 73C-146 | Case rear gasket | 1 | 69 | 0000103319 | 1/4 Lockwasher | 3 |
| 5 | L17-141 | Oil baffle spacer (no longer used) | 1 | 70 | 71-4 | Valve cover | 1 |
| 6 | 10-06-036-001 | Reduction oil baffle | 1 | 71 | 71-14 | Valve cover gasket | 1 |
| 7 | 0000115550 | 7/16 Lockwasher | 5 | N.I. | 73C-A244 (8) | Valve & spring ass'y. (Items 72, 73, 74, 75 & 76) | 1 |
| 8 | 0000179857 | 7/16-14 x 7/8 Hex head bolt | 5 | 72 | 4821 | Snap ring | 1 |
| 9 | 4765B | Snap ring | 1 | 73 | 71-246 | Valve spring retainer | 1 |
| 10 | L17-2 | Reduction output shaft | 1 | 74 | 5G-246 | Valve spring | 1 |
| 13 | 4822A | Ring gear snap ring | 1 | 75 | 73C-243 | Pressure regulator valve | 1 |
| 14 | L17-16 | Reduction ring gear hub | 1 | 76 | 73C-244 | Forward & reverse gear trans. valve | 1 |
| 15 | 73C-6 | Reduction ring gear | 1 | 77 | 4804H | "O" Ring | 1 |
| 16 | 4765B | Snap ring | 1 | 78 | 0000444864 | 3/8 Pipe plug | 1 |
| 17 | 4746 | Snap ring | 1 | 79 | 0000444592 | 3/4 Pipe plug | 1 |
| 18 | L17-4 | Reduction sun gear | 1 | 80 | 71C-A98A | Oil strainer assembly | 1 |
| 19 | 4765B | Snap ring | 1 | 81 | 73C-1A2E (9) | Output shaft & sleeve assembly | 1 |
| 20 | L14-A150 | Pinion cage assembly | 1 | 82 | 4830D (10) | Needle bearing | 1 |
| 21 | 4776BB | 7/16-14 x 7/8 Hex head bolt | 6 | 83 | 4832B (11) | Thrust bearing race | 1 |
| 22 | 0000141283 | Dowel pin | 2 | 84 | 4840R | Needle bearing | 1 |
| 23 | L17-8A | Bearing retainer | 1 | 85 | 73C-1A16E (12) | Input shaft & planet carrier assembly | 1 |
| 24 | 4775T | Main shaft nut | 1 | 86 | 4897A (13) | Pump drive key | 1 |
| 25 | 4914 | Coupling | 1 | 87 | 73C-6 | Ring gear | 1 |
| 26 | 10-00-044-017 (1) | Oil seal | 1 | 88 | 4832A | Needle thrust bearing race | 1 |
| 27 | L14-7 | Bearing retainer | 1 | 89 | 4830D | Needle bearing | 1 |
| 28 | 73C-147 | Bearing retainer gasket | 1 | 90 | 4832B | Thrust bearing race | 1 |
| 29 | 4920B | Bearing | 1 | 91 | Not serviced | Ring gear hub | 1 |
| 30 | 0000179861 | 7/16-14 x 1-3/8 Hex head bolt | 6 | 92 | 73C-A106A (14) | Ring gear hub & bushing assembly | 1 |
| 31 | 0000103322 | 7/16 Lockwasher | 6 | 93 | 71C-15 | Ring gear hub thrust washer | 1 |
| 32 | B308AG | Bearing | 1 | 94 | 4822A | Ring gear snap ring | 1 |
| 33 | 4804R | "O" Ring | 1 | 95 | 73C-71 | Reverse clutch pressure plate | 1 |
| 35 | 10-00-113-007 | Plug | 1 | 96 | 71)97 | Pressure plate spring | 12 |
| 36 | 4740A | Breather assembly—early type | 1 | 97 | 10-17-666-001 | Reverse clutch plate, inner | 4 |
| | 4740G | Breather assembly—pressure type | 1 | 98 | 72-176 | Reverse clutch plate, outer | 3 |
| 37 | 10-00-191-002 | 3/8 Plastic plug | 1 | 99 | 73C71 | Reverse clutch pressure plate | 1 |
| 38 | 0000444854 | 1/8 Pipe plug | 1 | 100 | 4622F | Dowel pin | 3 |
| 39 | 0000444864 | 3/8 Pipe plug | 1 | 101 | 4840T | Needle bearing | 1 |
| 40 | 71-2A195 | Dipstick assembly—screw-in type | 1 | 102 | 4805A | Sealing ring | 1 |
| N.I. | 10-06-559-001 | Dipstick assembly—new type | 1 | 103 | 71-35 | Reverse clutch piston | 1 |
| N.I. | 10-04-034-002 | Dipstick tube | 1 | 104 | 4806A | Sealing ring | 1 |
| 41 | 71-42 | Poppet spring | 1 | 105 | 4804G | Sealing ring | 1 |
| 42 | 0000453632 | 5/16 Steel ball | 1 | 106 | 000444858 | 1/4 Pipe plug | 1 |
| 43 | 68C-79 | Forward & reverse shift lever | 1 | 107 | 0000444854 | 1/8 Pipe plug | 1 |
| 44 | 0000115729 | 5/16-24 Hex nut | 1 | 108 | 73C-A8 | Trans. adapter & bearing assembly | 1 |
| 45 | 0000108579 | 5/16 Lockwasher | 1 | N.I. | 71C-A60 | Pump assembly (Items 109, 110, 112 & 113) | 1 |
| 46 | 0000103340 | Control lever washer | 1 | 109 | Not serviced | Pump drive gear (order assembly) | 1 |
| 47 | 0000453595 (17) | 7/16 Steel ball | 1 | 110 | Not serviced | Pump driven gear (order assembly) | 1 |
| 48 | 72M-273 (17) | Cooler check valve spring | 1 | 111 | 3-61 | Front pump gasket | 1 |
| 49 | 68C-268 (17) | Check valve spring retainer | 1 | 112 | Not serviced | Front pump housing (order assembly) | 1 |
| 50 | 68C-269 | Check valve spring | 1 | 113 | 10-00-044-014 (15) | Oil seal assem assembly | 1 |
| 51 | 10-06-565-001 (2) | Forward & reverse transmission case | 1 | 114 | 0000179822 | 5/16-18 x 1-1/2 Hex head bolt | 4 |
| 52 | 73C-140 | Oil baffle | 1 | N.I. | 10-00-183-021 (16) | 5/16-18 x 1-3/8 Hex head bolt | 4 |
| 53 | 73C-52A (3) | "O" ring backing plate | 2 | 115 | 73C-144 | Case & adapter gasket | 1 |
| 54 | 3-34 | "O" Ring | 1 | N.I. | 4636KR | Service name plate | 1 |
| 55 | 4806R | Sealing ring | 2 | N.I. | 000145366 | Drive screw | 1 |
| 56 | 73X-50A (4) | Direct clutch cylinder | 1 | 116 | 4911 | 3/8-16 x 1-1/4 Capscrew | 4 |
| 57 | 4559A | Snap ring | 1 | | | | |
| 58 | 3-46 | Sealing ring | 1 | | | | |
| 59 | 6-A45 (5) | Clutch piston & ball assembly | 1 | | | | |
| 60 | 3-65 (6) | Clutch plate (steel) | 6 | | | | |
| 61 | 12-A66 (7) | Clutch inner plate assembly | 6 | | | | |
| 62 | 5L-67 | Clutch pressure plate | 1 | | | | |
| 63 | 4751 | Snap ring | 1 | | | | |
| 64 | 3-47A | Clutch spring | 1 | | | | |
| 65 | 3-44 | Sealing ring | 1 | | | | |
| 66 | Not serviced | Bearing sleeve bushing (order ass'y.) | 1 | | | | |

NOTES 1-15: SEE PAGE 18

N.I. - NOT ILLUSTRATED



73C TRANSMISSION WITH 3.00:1 REDUCTION DRIVE

3.00:1 REDUCTION UNIT PARTS LIST FOR MODELS: 10-06-000-008 OR AS5-73C AND 10-06-000-009 OR AS5-73CR

| INDEX NO. | W.G. PART NO. | DESCRIPTION | NO. REQ'D. | INDEX NO. | W.G. PART NO. | DESCRIPTION | NO. REQ'D. |
|-----------|-------------------|---------------------------------------|------------|-----------|--------------------|--------------------------------------|------------|
| 1 | 000179860 | 7/16-14 x 1-1/4 Hex head bolt | 6 | 67 | 73C-A12A | Bearing sleeve & bushing assembly | 1 |
| 2 | 0000103322 | 7/16 Lockwasher | 6 | 68 | 0000179793 | 1/4-20 x 5/8 Hex head bolt | 1 |
| 3 | L14-1 | Reduction unit housing | 1 | | 0000179791 | 1/4-20 x 1/2 Hex head bolt | 1 |
| 4 | 73C-146 | Case rear gasket | 1 | 69 | 0000103319 | 1/4 Lockwasher | 1 |
| 5 | L17-141 | Oil baffle spacer (no longer used) | 1 | 70 | 71-4 | Valve cover | 1 |
| 6 | 10-06-036-001 | Reduction oil baffle | 1 | 71 | 71-14 | Valve cover gasket | 1 |
| 7 | 000115550 | 7/16 Lockwasher | 5 | N.I. | 73C-A244 | Valve & spring assembly | |
| 8 | 0000179857 | 7/16-14 x 7/8 hex head bolt | 5 | | | (items 72, 73, 74, 75 & 76) | 1 |
| 9 | 4765B | Snap ring | 1 | 72 | 4821 | Snap ring | 1 |
| 10 | L14-A150 | Pinion cage assembly | 1 | 73 | 71-246 | Valve spring retainer | 1 |
| 13 | L17-2 | Reduction output shaft | 1 | 74 | 5G-246 | Valve spring | 1 |
| 14 | 4765B | Snap ring | 1 | 75 | 73C-243 | Pressure regulator valve | 1 |
| 15 | 4746 | Snap ring | 1 | 76 | 73C-244 (8) | Forward & reverse gear trans. valve | 1 |
| 16 | L17-4A | Reduction sun gear | 1 | 77 | 4804H | "O" Ring | 1 |
| 17 | 4765B | Snap ring | 1 | 78 | 0000444864 | 3/8 Pipe plug | 2 |
| 18 | 73C-6 | Reduction ring gear | 1 | 79 | 0000444592 | 3/4 Pipe plug | 1 |
| 19 | L17-16 | Reduction ring gear hub | 1 | 80 | 71C-A98A | Oil strainer assembly | 1 |
| 20 | 4822A | Ring gear snap ring | 1 | 81 | 83C-1A2E (9) | Output shaft & sleeve assembly | 1 |
| 21 | 4776BB | 7/16-14 x 7/8 Hex head bolt | 6 | 82 | 4830D (10) | Needle bearing | 1 |
| 22 | 000141283 | Dowel pin | 2 | 83 | 4832B (11) | Thrust bearing race | 1 |
| 23 | L17-8A | Bearing retainer | 1 | 84 | 4840R | Needle bearing | 1 |
| 24 | 4775T | Main shaft nut | 1 | 85 | 73C-1A16E (12) | Input shaft & planet carrier ass'y. | 1 |
| 25 | 4914 | Coupling | 1 | 86 | 4897A (13) | Pump drive key | 1 |
| 26 | 10-00-044-017 (1) | Oil seal | 1 | 87 | 73C-6 | Ring gear | 1 |
| 27 | L14-7 | Bearing retainer | 1 | 88 | 4832A | Needle thrust bearing race | 1 |
| 28 | 73C-147 | Bearing retainer gasket | 1 | 89 | 4830D | Needle bearing | 1 |
| 29 | 4920B | Bearing | 1 | 90 | 4832B | Thrust bearing race | 1 |
| 30 | 0000179861 | 7/16-14 x 1-3/8 Hex head bolt | 6 | 91 | Not serviced | ring gear hub bushing (order ass'y.) | 1 |
| 31 | 0000103322 | 7/16 Lockwasher | 6 | 92 | 73C-A106A (14) | Ring gear hub & bushing assembly | 1 |
| 32 | B308AG | Bearing | 1 | 93 | 71C-15 | Ring gear hub thrust washer | 1 |
| 33 | 4804R | "O" Ring | 1 | 94 | 4822A | Ring gear snap ring | 1 |
| 35 | 10-00-113-007 | Plug | 1 | 95 | 73C-71 | Reverse clutch pressure plate | 1 |
| 36 | 4740A | Breather assembly—early type | 1 | 96 | 71-97 | Pressure plate spring | 12 |
| | 4740G | Breather assembly—pressure type | 1 | 97 | 10-17-666-001 | Reverse clutch plate, inner | 4 |
| 37 | 10-00-191-002 | 3/8 Plastic plug | 1 | 98 | 71-176 | Reverse clutch plate, outer | 3 |
| 38 | 0000444854 | 1/8 Pipe plug | 1 | 99 | 73C-71 | Reverse clutch pressure plate | 1 |
| 39 | 0000444864 | 3/8 Pipe plug | 1 | 100 | 4622F | Dowel pin | 3 |
| 40 | 71-2A195 | Dipstick assembly—screw-in type | 1 | 101 | 4840T | Needle bearing | 1 |
| N.I. | 10-06-559-001 | Dipstick assembly—latest type | 1 | 102 | 4805A | Sealing ring | 1 |
| N.I. | 10-04-034-002 | Dipstick tube | 1 | 103 | 71-35 | Reverse clutch piston | 1 |
| 41 | 71-42 | Poppet spring | 1 | 104 | 4806A | Selasing ring | 1 |
| 42 | 0000453632 | 5/16 Steel ball | 1 | 105 | 4804G | Sealing ring | 1 |
| 43 | 68C-79 | Forward & reverse shift lever | 1 | 106 | 0000444858 | 1/4 Pipe plug | 1 |
| 44 | 000115729 | 5/16-24 Hex nut | 1 | 107 | 0000444854 | 1/8 Pipe plug | 1 |
| 45 | 0000108579 | 5/16 Lockwasher | 1 | 108 | 73C-A8 | Trans. adapter & bearing assembly | 1 |
| 46 | 0000103340 | Control lever washer | 1 | N.I. | 71C-A60 | Pump assembly | |
| 47 | 0000453595 (17) | 7/16 Steel ball | 1 | | | (Items 109, 110, 112 & 113) | 1 |
| 48 | 72M-272 (17) | Cooler check valve spring | 1 | 109 | Not serviced | Pump drive gear (order assembly) | 1 |
| 49 | 68C-268 (17) | Check valve spring retainer | 1 | 110 | Not serviced | Pump driven gear (order assembly) | 1 |
| 50 | 68C-269 | Check valve spring | 1 | 111 | 3-61 | Pump gasket | 1 |
| 51 | 10-06-565-001 (2) | Forward & reverse transmission case | 1 | 112 | Not serviced | Pump housing (order assembly) | 1 |
| 52 | 73C-140 | Oil baffle | 1 | 113 | 10-00-044-014 (15) | Oil seal assembly | 1 |
| 53 | 73C-52A (3) | "O" Ring backing plate | 2 | 114 | 0000179822 | 5/16-18 x 1-1/2 Hex head bolt | 4 |
| 54 | 3-34 | "O" Ring | 1 | N.I. | 10-00-183-021 (16) | 5/16-18 x 1-3/8 Hex head bolt | 4 |
| 55 | 4806R | Sealing ring | 2 | 115 | 73C-144 | Case & adapter gasket | 1 |
| 56 | 73C-50A (4) | Direct clutch cylinder | 1 | N.I. | 4636KR | Service name plate | 1 |
| 57 | 4559A | Snap ring | 1 | N.I. | 0000145366 | Drive screw | 2 |
| 58 | 3-46 | Sealing ring | 1 | 116 | 4911 | 3/8-16 x 1-1/4 Capscrew | 4 |
| 59 | 6-A45 (5) | Clutch piston & ball assembly | 1 | | | | |
| 60 | 3-65 (6) | Clutch plate (steel) | 6 | | | | |
| 61 | 12-A66 (7) | Clutch inner plate assembly | 6 | | | | |
| 62 | 5L-67 | Clutch pressure plate | 1 | | | | |
| 63 | 4751 | Snap ring | 1 | | | | |
| 64 | 3-47A | Clutch spring | 1 | | | | |
| 65 | 2-44 | Sealing ring | 1 | | | | |
| 66 | Not serviced | Bearing sleeve bushing (order ass'y.) | 1 | | | | |

NOTES 1-15: SEE PAGE 18

N.I. - NOT ILLUSTRATED

PARTS INTERCHANGEABILITY

- 1) Oil seal 10-00-044-017 replaces seal L14-110A.
 - 2) 10-06-565-001 forward and reverse transmission case replaces the 73C-1 and 73C-1A cases.
 - 3) 73C-52A "O" ring backing plate replaces 73C-52 plate which was thinner. These plates are not used when 73C-50 direct clutch cylinder is used.
 - 4) 73C-50A direct clutch cylinder replaces 73C-50 clutch cylinder. 73C-50A cylinder is undercut to accommodate the 3-34 "O" ring under rear portion of clutch hub. 73C-50A cylinder may be used with "O" ring positioned behind bearing when sun gear and output shaft have the "O" ring groove in this location.
 - 5) 6-A45 clutch piston and ball replaces 5M-45A clutch piston, which had no ball.
 - 6) 3-65 coned steel clutch plate replaced 3-176A flat steel clutch plate. Six of the 3-65 plates replace seven of the 3-176A plates. Change No. 7 was made in conjunction with this change.
 - 7) 5C-A66A clutch inner plate assembly replaces 5C-A66 clutch plate. Six 5C-A66A plates used with six 3-65 plates replace seven 5C-A66 plates used with seven 3-176A plates. 12A-66 plates are now used.
 - 8) 73C-A244 valve and spring assembly replaces 68C-A244 valve and spring assembly. These two assemblies are interchangeable; however, individual parts should not be interchanged.
- Items 9, 10, 11 and 12 are used together and should not be interchanged with earlier parts used in these locations.
- 9) 73C-1A2F or 73C-1A2E output shaft and sleeve assembly.
 - 10) 4830D needle bearing.
 - 11) 4832B thrust bearing race.
 - 12) 73C-1A16E input shaft and planet carrier assembly.

Transmissions having serial numbers prior to 423 for AS1-73C and CR units, 335 for AS2-73C and CR units, 1138 for AS5-73C and CR units, or 534 for AS7-73C and CR units will have the following parts which should be used together; 73C-A2 output shaft and sleeve assembly, 73C-1A16 input shaft and planet carrier assembly, 4830C needle bearing, and 4832 thrust bearing race. These early parts have a smaller thrust bearing and thrust faces are too small to be used with later parts.

13) 4897A pump drive key is the current key which replaced 4873 pump drive key. These two keys are not interchangeable. Units with serial numbers prior to those listed below will use the 4873 key:

| | |
|----------------|-----|
| AS1-73C and CR | 203 |
| AS2-73C and CR | 149 |
| AS5-73C and CR | 220 |
| AS7-73C and CR | 210 |

14) 73C-A106A ring gear hub and bushing assembly replaces and is interchangeable with 73C-A106 ring gear hub without a bushing.

15) 71C-62A oil seal assembly replaces and is interchangeable with 71C-62 oil seal assembly. 71C-62A has a double lip and 71C-62 has a single lip.

16) A shorter pump housing is now being supplied. The new pump requires the 5/16-18 x 1-3/8 hex head bolt and the earlier pump requires 5/16-18 x 1-1/2 hex head bolt. Be sure to use the correct bolts.

17) These parts were changed as follows:

- 1 68C-269 spring removed
- 1 was 2 453595 7/16 steel ball
- 1 was 2 68C-268 check valve spring

REQUEST FOR SERVICE INFORMATION

Service questions can not be intelligently answered without a complete knowledge of the nature of the problem, the model number of the transmission involved and all pertinent information. the following list indicates information that should be included when writing or phoning for assistance:

- 1) Model number and date purchased.
- 2) Serial number.
- 3) Transmission ratio
- 4) Engine used with transmission
- 5) Type of equipment in which used
- 6) Describe symptoms
- 7) Is transmission operative in forward
- 8) Is transmission operative in reverse
- 9) Does transmission slip in forward
- 10) Does transmission slip in reverse
- 11) Where from full mark was oil level

- 12) Was transmission noisy. (describe)
- 13) What was transmission line pressure, (see manual and check)
- 14) Did transmission lock-up
- 15) Was excessive heat noted at or near time of failure, (Describe)
- 16) Was shift lever correctly positioned by poppet ball in all positions
- 17) Was anything peculiar noticed prior to failure, (Describe)
- 18) What type of oil is being used
- 19) Is an oil cooler properly connected to transmission

If model or serial number can not be read from name tag, look for it on sales contract or ask your dealer. The service manual will identify some models clearly; however, when all efforts fail, include all information that would help identify your transmission.

REPAIR KITS FOR MODEL 73C

SMALL PARTS REPAIR KIT — KIT NO. A4867DW

| PART NO. | PART NAME | QTY. |
|---------------|---|------|
| 73C-144 | Gasket-case & adapter | 1 |
| 73C-146 | Gasket-case, rear | 1 |
| 73C-147 | Gasket-bearing retainer, reduction & direct drive | 1 |
| 71-14 | Gasket-valve cover | 1 |
| 10-00-044-014 | Oil seal, pump | 1 |
| 10-00-044-017 | Oil seal, rear | 1 |
| 3-61 | Gasket-front pump | 1 |
| 4805A | Seal ring, reverse clutch piston | 1 |
| 4804G | Seal ring, reverse clutch cylinder | 1 |
| 3-46 | Seal ring, forward clutch piston | 1 |
| 3-44 | Seal ring | 1 |
| 3-34 | Seal ring | 1 |
| 4804R | Seal ring | 1 |
| 4806A | Sealing ring | 1 |
| 4806R | Sealing ring | 2 |
| 4822A | Snap ring | 2 |
| 4559A | Snap ring | 1 |
| 4751 | Snap ring | 1 |
| 4746 | Snap ring | 1 |
| 4765B | Snap ring | 2 |
| 4745E | Snap ring | 1 |
| 73C-15 | Ring gear hub thrust washer | 1 |
| 4804H | "O" Ring, selector valve | 1 |
| 453632 | Poppet ball | 1 |
| 71-42 | Poppet spring | 1 |
| 4897A | No. 9 Key, pump | 1 |
| 71-97 | Reverse clutch pressure plate spring | 4 |
| 4622F | Dowel pin, reverse clutch | 3 |
| 4775T | Main shaft nut | 1 |
| 4652KK | 7/16 Steel ball | 1 |
| 4821 | Snap ring | 1 |
| 73C-52A | "O" ring backing plate | 2 |

GASKET, OIL SEAL & SEALING RING KIT NO. A4867HB

| PART NO. | PART NAME | QTY. |
|---------------|------------------------------------|------|
| 73C-144 | Gasket-case & adapter | 1 |
| 73C-146 | Gasket-case rear | 1 |
| 73C-147 | Gasket-bearing retainer, reduction | 1 |
| 71-14 | Gasket-valve cover | 1 |
| 3-61 | Gasket-front pump | 1 |
| 4805A | Seal ring—reverse clutch piston | 1 |
| 4804G | Seal ring—reverse clutch cylinder | 1 |
| 3-46 | Seal ring—forward clutch piston | 1 |
| 3-44 | Seal ring | 1 |
| 3-34 | Seal ring | 1 |
| 4804R | Seal ring | 1 |
| 10-00-044-014 | Oil seal—pump | 1 |
| 10-00-044-017 | Oil seal—rear | 1 |

DISASSEMBLY OF TRANSMISSION

PROCEDURES FOR ALL MODELS

The number following a part name in this section refers to the part as illustrated in the "Direct Drive Exploded View"

- 1) Disassembly procedure should not begin until transmission exterior and work area have been thoroughly cleaned.
- 2) Remove all pipe plugs, all fittings, filler plug, drain plug and oil screen. Permit remaining fluid to drain from transmission.
- 3) Place transmission upright on a bench. Remove the four pump to adapter bolts. Use a plastic hammer to free pump as it is pulled from input shaft. Do not damage pump bolt bosses. Pump bolts seal against these faces.
- 4) Use a felt marking pen to mark gears so that they may be replaced in original position. Press the oil seal from pump housing and discard seal and gasket.
- 5) Remove the four adapter to case bolts (84) and pull adapter (83) from front of transmission. A large plastic hammer may be needed to help free adapter from snap fit of transmission case. Catch and remove clutch pressure plate as the adapter is removed.
- 6) Blow air into adapter clutch feed hole to force piston (77) from adapter. Remove and discard adapter gasket and clutch sealing rings.
- 7) Remove the three dowel pins (75) which hold clutch outer plates from turning. Remove clutch return springs.
- 8) Pull input shaft and planetary carrier assembly (62) forward to remove ring gear, pinion cage assembly and remaining reverse clutch plates from transmission.
- 9) Remove reverse clutch plates from ring gear and thrust washer (69) from ring gear hub (68). Remove ring gear and ring gear hub from pinion cage assembly. Remove thrust needles (59) and one thrust race (66) from carrier and the other thrust race (60) from ring gear hub.
- 10) Ring gear and ring gear hub (68) may be separated by removing the snap ring (70).
- 11) Remove needle thrust bearing (59) from front face of sun gear (54). A thrust plate (60) will be found inside the pinion cage assembly and it should be removed for inspection.

12) Remove nut, lockwasher and flat washer from shift lever, then remove shift lever (22).

13) Remove valve cover bolts (41), lockwashers, valve cover (6) and gasket.

14) Remove valve assembly from case. Press against spring retainer (38) to prevent parts from springing out as snap ring (42) is removed from valve. Remove spring and regulator valve from forward and reverse valve (45).

TO COMPLETE DISASSEMBLY OF FORWARD AND REVERSE TRANSMISSION

- 1) Use a tool similar to the one shown in Fig. 6 to press against the end of sun gear and output shaft (54), while completing steps two through five, inclusive.
- 2) Remove output shaft nut and coupling from output shaft.
- 3) Remove bearing retainer to case bolts (4) and lockwashers. Remove bearing retainer (7) and bearing spacer (12) from transmission case. It may be necessary to use a large plastic hammer to help free retainer from case.
- 4) Remove the "O" ring (9) from behind bearing.
- 5) Remove bearing components from output shaft.
- 6) Remove the tool and pull output shaft and forward clutch assembly forward from case.
- 7) Remove the snap ring (58) from clutch cylinder.
- 8) Invert the clutch assembly and catch clutch plates as they slide from clutch cylinder.

9) Press clutch cylinder from shaft and piston.

10) Position remaining clutch parts, with a tool similar to the one illustrated in Fig. 7 on an arbor press and compress clutch return spring, then remove snap ring (34) from behind clutch piston.

11) Remove clutch piston (36), and spring (50) from sun gear and output shaft (54). Remove sealing ring from clutch piston.

12) Remove the two cast iron sealing rings (32) from rear of clutch housing.

13) Inspect the bearing cups (10) in case and retainer. Remove only if replacement of cups is required.

14) Remove and discard oil seal from bearing retainer.

DISASSEMBLY OF REDUCTION UNITS

PROCEDURES FOR ALL MODELS

Procedure in this section applies to all reduction units and should follow steps outlined in section "Procedure for All Models". Numbers which follow a part name refer to this part on the appropriate reduction unit exploded view.

1) Remove six reduction housing to case bolts and slide reduction housing with attached parts rearward from forward and reverse transmission.

2) Use a tool similar to the one shown in Fig. 6 to press against the end of sun gear and output shaft, while removing the snap ring which retains reduction unit gears to forward and reverse transmission output shaft. Slide reduction unit parts from shaft.

3) Complete steps six through twelve inclusive of section "To Complete Disassembly of Forward and Reverse Transmission" except, following step No. 8, complete the following instruction: Place clutch cylinder and sun gear under an arbor press and compress clutch spring to permit removal of "O" ring backing plates (53) and "O" ring (54). The "O" will be positioned in the shaft groove behind the annular bearing on a few early transmissions.

4) Remove the snap ring (17) from bearing retainer (23) and remove ring gear (18) and ring gear hub (19) from 3:1 units. Remove snap ring (19) and pinion cage assembly (20) from 2:1 units.

5) Remove bearing retainer to case bolts and retainer from transmission case rear face.

6) Pull bearing (32) from case. It will be necessary to remove the snap ring (23) from bearing snap ring groove on 1.5:1 units, so that a puller may be installed in bearing groove.

7) Remove output shaft nut and coupling from output shaft, then remove output shaft with attached parts from reduction housing.

8) Remove bearing retainer to reduction housing bolts (1). Remove bearing retainer (27) and rear bearing cone.

9) Bearing outer race may be removed by pressing on front face of front bearing cone.

10) Press seal from bearing retainer.

TO COMPLETE DISASSEMBLY OF 2:1 REDUCTION UNITS

1) Remove the two snap rings (9 & 16) from output shaft and slide ring gear hub (14) from output shaft.

2) Ring gear may be separated from ring gear hub after removing the snap ring (13).

3) Remove oil baffle to reduction housing bolts (8) then remove baffle and spacer.




FIG. 6 PRESS AGAINST SUN GEAR SHAFT.

TO COMPLETE DISASSEMBLY OF 3:1 REDUCTION UNITS

- 1) Separate ring gear (18) and hub (19) after removing snap ring (20).
- 2) Remove the two snap rings (9 & 14) from output shaft, then slide pinion cage (10) from shaft.
- 3) Remove oil baffle to reduction housing bolts (8), oil baffle (6) and spacer (5) from reduction housing.




FIG. 7 ASSEMBLE PISTON & SNAP RING

TO COMPLETE DISASSEMBLY OF 1.5:1 REDUCTION UNITS

- 1) Remove the two snap rings and pinion cage from output shaft.
- 2) Remove sun gear to reduction housing bolts, oil baffle and sun gear from reduction housing.
- 3) Ring gear may be separated from ring gear hub after snap ring is removed from ring gear.




FIG. 8 ASSEMBLE "O" RING AND BACKING PLATES




FIG. 9 DOWELS USED TO RETAIN SPRINGS

ASSEMBLY OF TRANSMISSION

ALL MODELS

The procedure described in this section is the same for all ratios. Index numbers used in this section refer to the part as shown in the "Direct Drive Transmission" exploded view Page 10.

1) An orifice plug (37) should be pressed in the drilled passage which angles down from the cast passage in case rear face connecting to bearing bore. A plug (37A) without an orifice is pressed into the upper left passage which angles up to connect with the valve bore of direct drive units only. The plugs will normally be in position; however, new cases may be received with plugs omitted.

NOTE: Early cases will not have the passage which angles down to connect with bearing bore and the orifice plug was not required in these cases. A second plug without an orifice should be pressed in the right hand passage on direct drive units only which use this early case. These cases are interchangeable.

2) Assemble regulator valve (44) and spring (43) into shift valve (45) bore. Press spring retainer (38) into place and install snap ring (42) in valve groove. The retainer should offset away from spring.

3) Assemble the "O" ring (46) in shift valve groove. Lubricate and assemble valve and spring assembly into case bore. The slot in end of valve should be aligned with the lower valve body cover bolt hole.

4) Assemble a new valve cover gasket (39), valve cover (6) and three 1/4-20 X 5/8 hex head bolts (41) with lockwashers (40).

5) Assemble shift lever (22), detent spring (20), detent ball (21), control lever washer (23), lockwasher (24) and nut (25). Spring and ball should be liberally greased to prevent rust caused by salt water entering spring bore.

6) Replace all pipe plugs, oil screen (49), drain plug (48) and dipstick (19).

7) Assemble oil baffle (30) into case (29).

8) Assemble an "O" ring (51) in shaft (54) groove nearest sun gear. Lubricate the "O" ring. Place clutch piston return spring (50) on shoulder of bearing sleeve (53).

NOTE: Bearing sleeve (53), bearing sleeve bushing (52) and output shaft (54) are an assembly and normally are not disassembled. The bushing was not used in early transmissions. The new shaft with bushings may be used to replace a shaft which has no bushing.

9) Assemble a sealing ring (35) in forward clutch piston (36) groove. Lubricate the sealing ring and position piston over sun gear shaft and rest on spring.

10) Place parts assembled in steps eight and nine in an arbor press and with a tool similar to the one shown in Fig. 7, press the piston and spring down, then assemble a snap ring (34) in shaft groove behind piston.

11) Assemble clutch cylinder (33) over output shaft and piston assembly. Check, after assembling these parts, to be sure that clutch sealing rings were not sheared or damaged.

12) Start with a steel plate (56) and alternate friction (55) and steel plates until six sets of plates, a pressure plate (57) and snap ring (58) are assembled into clutch cylinder. The steel plates are coned to give a better clutch release in neutral. The cone of all steel plates should face in the same direction, preferably concave forward.

NOTE: Seven sets of flat steel plates were used with seven friction plates in a few early units. A full set of the new clutch plates should be used to replace a set of these early plates.

13) Assemble two cast iron sealing rings (32) into clutch cylinder (33) hub grooves.

TO COMPLETE ASSEMBLY OF DIRECT DRIVE TRANSMISSION

1) Press a bearing cup (10) into transmission case bore. Press a bearing cup into bearing retainer. These cups will normally be left in position and replacement will not be required. Press a new oil seal (3) into bearing retainer until rear face of seal is flush with retainer rear face.

2) Assemble the bearing spacer (31) over output shaft and against clutch cylinder rear face.

- 3) Assemble clutch and output shaft assembly into transmission case, being careful to prevent damaging the two cast iron sealing rings, as they enter the transmission case bore.
- 4) Install the tool Fig. 6 to front of case and adjust the screw against front face of shaft to press parts rearward until they just bottom on case.
- 5) Assemble bearing cones (11) back to back over output shaft and against the spacer.
- 6) Assemble an "O" ring (9) in output shaft groove just behind the rear bearing cone.
- 7) Assemble the lube line cover (14) and the two retaining bolts (13). A few early cases do not require this lube line cover.
- 8) Assemble case rear gasket (8) to case. Assemble the bearing spacer (12) into retainer bore then assemble retainer to transmission. Replace the six 7/16-14 X 1 inch hex head bolts (4) and lockwashers (5).
- 9) Assemble coupling (2) and output shaft nut (1) then remove the tool from front of transmission case. Permatex or a similar sealer should be applied to output shaft splines and under output shaft nut to prevent leakage around shaft splines.
- 10) Stand the transmission on it's coupling and install the thrust needles (59) on front face of sun gear.
- 11) Inspect the needle bearing (61) which is located in input shaft and carrier assembly bore, and replace if necessary. Press a new bearing in until rear face is 7/8 inch below rear face of carrier assembly.
- 12) Assemble needle thrust bearing race (60), with flange facing forward, into bore and against face of input shaft and carrier assembly.
- 13) Use a twisting motion to align gear teeth and clutch plate teeth with mating parts as the input shaft and carrier assembly are lowered over sun gear and into direct clutch.
- 14) Place the flat needle thrust race (66) followed by the needle thrust bearing (59) on the forward thrust face of carrier assembly.
- 15) Assemble the cast iron sealing ring (64) in input shaft groove.
- 16) Assemble ring gear hub (68) into splines of ring gear (65) and install the snap ring (70) in ring gear groove. Early

ring gear hubs did not have a bushing (67). The present ring gear hub with a bushing may be used to replace the earlier hub without a bushing.

- 17) Assemble thrust race (60) with flange toward ring gear hub.
- 18) Use a twisting motion to align gear teeth as the ring gear and hub are lowered over input shaft and carrier assembly.
- 19) Assemble the thrust washer (69) on front face of ring gear hub.
- 20) Assemble a reverse clutch pressure plate (71) positioned with the "V" notch aligned with the lower left bolt hole at front of case.
- 21) Assemble the three dowel pins (75) in the half moon cut-outs in case reverse clutch bore.
- 22) Assemble an inner reverse clutch plate (73) over ring gear hub splines and alternating with steel outer plates (74) aligned with dowel pins, assemble four inner and three outer plates in the reverse clutch cavity. Place the odd shaped lug of steel plates over the uppermost dowel to permit clearance with spring.
- 23) Install twelve clutch return springs (72) and place a dowel pin inside each spring. Make dowels 3/16 inches in diameter and approximately 2-1/4 inches long. Dowels hold springs during assembly and must fit holes in pressure plate Fig. 9.
- 24) Install the other clutch pressure plate (71) aligning the dowel pins with pressure plate holes and with the cast "V" in pressure plate aligned with lower left bolt hole in case face. Remove the twelve dowel pins after the upper pressure plate is firmly seated against the twelve springs.
- 25) Inspect needle bearing (80) which is located in adapter bore and replace if necessary.
- 26) Assemble reverse clutch sealing ring (76) in reverse clutch piston (77) groove and assemble "O" ring (78) in adapter (83) hub groove. Lubricate and press piston in clutch cylinder bore of adapter.
- 27) Assemble a gasket over snap fit on adapter face. Use petrolatum to hold the gasket in position. Carefully lower the adapter into contact with case face. Assemble the four 3/8-16 X 1-1/4 adapter bolts (84) to retain the adapter to the case.

28) Press a new seal (89) into pump housing (88) until seal is flush with front face of housing.

29) Assemble pump drive key (63) in input shaft groove then assemble the pump drive gear (85) over shaft and key.

Two different keys have been used and the shaft has two different keyways to accept one of the keys. The correct key must be selected for each shaft.

30) Assemble pump driven gear (86) into pump housing (88). Place pump gasket (87) in adapter pump counterbore then assemble pump housing with gear on adapter. Assemble four pump bolts to retain pump to adapter. A seal pro-

tector should be assembled over shaft splines to protect pump seal.

CAUTION: The pump can be assembled in either one of two positions. In each position, the pump will only pump oil when rotated in the direction that the arrow at top of the pump is pointing.

A new shorter pump housing is being placed in production. This pump is interchangeable with the earlier pump. The pump to adapter bolts used with the early pump were 5/16-18 X 1-1/2 hex head bolts and the new pump uses 1-3/8 inch long bolts. **CAUTION:** Be sure to use the correct length of bolt.

ASSEMBLY OF TRANSMISSION WITH REDUCTION UNIT

The index numbers which follow a part name in this section refers to the part in the appropriate reduction unit exploded view.

1) Complete all steps as outlined in section "All Models".

2) Press the ball bearing (32) into case bore. The bearing snap ring groove should be to rear and a snap ring (23) should be assembled in the groove of bearings used in 1.5 to 1 reduction units.

3) Assemble bearing retainer (23 or 22) and six 7/16-14 X 1 hex head bolts (21) to rear face of case. Lockwashers (21) are used on 1.5:1 units only. Dowels (22) are used to prevent bearing retainer from shifting on 2 to 1 and 3 to 1 ratio units; however, early units were not doweled. Doweled cases and retainers are both interchangeable. Doweled retainers are recommended.

4) Parts assembled in steps 8 through 13 in the section "All Models" should be placed in an arbor press and using a tool as shown in Fig. 8, press the clutch cylinder down against the clutch spring. The sealing ring groove will now be exposed. Assemble sealing ring (54) into shaft groove and work the seal under clutch cylinder counterbore so that the two half moon backing plates (53) may be assembled behind the seal. Carefully release arbor press, making certain that the clutch cylinder bore returns back over the two half moon retainers.

NOTE: Early transmissions will not have the "O" ring located under clutch counterbore. The "O" ring will be assembled later in these units.

5) Assemble clutch pack and sun gear to transmission case

and use a tool similar to the one shown in Fig. 6 to press against sun gear shaft until the snap ring is installed in shaft groove.

6) Assemble an "O" ring in the shaft groove behind the bearing on early units which do not have this "O" ring installed under the clutch cylinder hub as described in step No. 4.

7) Assemble an "O" ring (33) into the shaft groove near end of shaft.

7a) For 1.5 to 1 Units Only:

1) Assemble ring gear (16), ring gear hub (18) and snap ring (20), then assemble these parts over output shaft splines.

2) Assemble snap ring (17) into output shaft groove behind ring gear hub.

7b) For 2:1 Units Only

1) Assemble pinion carrier assembly (20) over bearing retainer splines, then assemble a snap ring (19) into retainer groove behind carrier. Splines assemble in one position only.

2) Assemble sun gear (18) over forward and reverse transmission output shaft splines. This gear is identified by a single groove around gear hub.

3) Assemble a snap ring (17) into output shaft groove to retain sun gear to shaft.

7c) For 3:1 Units Only

- 1) Assemble ring gear (18), ring gear hub (19), and snap ring (20), then assemble these parts over bearing retainer (23). The splines will assemble in one position only.
- 2) Assemble a snap ring (17) into bearing retainer groove behind ring gear hub.
- 3) Assemble sun gear (16) over splines of forward and reverse transmission output shaft and replace snap ring (15) to retain sun gear to output shaft. The 3:1 sun gear may be identified by the two grooves around gear hub.
- 8) Remove the tool installed in step No. 5. Stand the transmission on end on the parts assembled in steps 7a, 7b and 7c, then complete steps 10 through 30 of section "To Complete Assembly of Direct Drive Transmission".
- 9) Press outer race of bearing (29) into reduction housing and seat against shoulder.
- 10) Press a new seal (26) into reduction unit bearing retainer (27). Seal and retainer faces should be flush.
- 11) Place rear bearing cone into bearing race then assemble bearing retainer, gasket (28) and six 7/16–14 X 1–1/4 hex head bolts (1) and lockwashers.

NOTE: Bearing components are matched. The cup, spacer and two cones will all have the same number with the cup and one spacer having an "A" Suffix. Place the cone with the "A" Suffix in the end of the cup which has the Suffix "A". Do not interchange bearing components.

12) For 1.5:1 Units Only

- 1) Assemble bearing spacer, front cone, sun gear (5) and oil baffle (6) into reduction housing and use five 7/16–14 X 7/8 hex head bolts (7) to retain these parts.
- 2) Assemble a snap ring (8) into output shaft (10) rear groove. Assemble carrier assembly (9) over shaft splines and into contact with snap ring.
- 3) Assemble a snap ring (15) into shaft front groove in front of carrier then assemble these parts into reduction housing.
- 4) Apply permatex or another suitable sealer to shaft splines and under nut as coupling (25) and nut (24) are assembled to the output shaft.

12a) For 2:1 Units Only

- 1) Assemble oil baffle spacer (5), oil baffle (6) and five 7/16–14 X 7/8 hex head bolts (8) with lockwashers to reduction housing.
- 2) Assemble ring gear (15), ring gear hub (14), and snap ring (13).
- 3) Assemble snap ring (9) in rear output shaft groove, then assemble hub splines over shaft splines and install a snap ring (16) in shaft front groove. Hub and shaft splines will assemble in one position only.
- 4) Assemble front bearing cone and spacer over output shaft.
- 5) Assemble output shaft and attached parts into reduction housing, then replace coupling (25) and nut (24). Use permatex or another suitable sealer on shaft splines and under nut to insure against leakage.

12b) For 3:1 Units Only

- 1) Assemble oil baffle spacer (5), oil baffle (6) and five 7/16–14 X 7/8 hex head bolts into reduction housing.
- 2) Assemble a snap ring (14) in output shaft front groove, slide carrier over shaft splines and replace the snap ring (9) in shaft rear groove. Carrier and shaft splines will assemble in one position only.
- 3) Assemble front bearing cone and spacer over output shaft.
- 4) Assemble carrier and output shaft assembly with bearing components into reduction housing and replace coupling and nut. Use permatex or another suitable sealer on shaft splines and under nut to insure against leakage.
- 13) Assemble a gasket (4) to transmission case rear face, then assemble reduction housing with attached parts to forward and reverse transmission. A gentle twisting of the coupling will help align gears. Assemble six 7/16–14 X 1–3/4 hex head bolts (30) with lockwashers (31) to retain reduction unit to forward and reverse transmission.

SERVICE PRECAUTIONS AND INSTRUCTIONS

SERVICE REQUIREMENTS

Modern hydraulic transmissions require good servicing, if they are to function properly. Knowledge of all transmission components, oil cooler, cooler lines and connections, hydraulic circuits and all external controls is necessary to insure reliable, dependable, economical and trouble free operation.

Good service starts with knowledge. The most important factor for good servicing is cleanliness. Hydraulic valves and transmission parts have very close tolerances and small particles of dirt or lint will cause valves to stick or may cause damage to hydraulic sealing surfaces of transmission components. Good service requires careful workmanship and a craftsman's attitude. Take nothing for granted and check everything.

CHECKING AND CLEANING COOLER

Flush all oil and dirt from external oil lines and oil cooler before installing a new or an overhauled transmission. This is especially necessary if a damaged transmission, contaminated by wear particles, was permitted to run and circulate contaminated oil through cooler circuits.

SHIFT LINKAGE

Adjust and check linkage after each installation and at other times when transmission functioning indicates a need for linkage adjustment. Transmission will operate properly only if the shift lever is located with the ball poppet fully seated in the hole in the side of shift lever.

CHECKING AND CHANGING FLUID

Check fluid level when transmission is at operating temperature and immediately after stopping engine. Drain oil once per season and refill with fluid. Low oil level should be reason to check for leakage from external fittings and around seals and gaskets.

(SEE PAGE 7 FOR TYPE OF OIL)

INTERNAL LEAKS

Leakage may be caused by many factors. Look, when checking for leaks, for broken sealing rings (cast iron or rubber), scratched surfaces, loose bolts, foreign particles between mating surfaces or surfaces which are not flat. Surfaces may be lapped to correct flatness. Damaged seals and sealing rings may be replaced. torque loose bolts.

CHECKING PRESSURES

Use test gauges when trouble shooting. Gauges must be accurate to be of any value. Check the various hydraulic oil pressures by installing suitable gauges (a 0 to 200 PSI [0-1379 k Pa] gauge for clutches, 0 to 100 [0-690 k Pa] for cooler, and 0-50 [0-359 k Pa] for lube) in the outlets indicated in Figs. 1 and 2. Clutch pressures should be between 125 and 160 PSI (862-1103 k Pa) when engine speed is 2000 RPM and sump temperature is from 140° to 190°F (49-60c). Check reverse clutch when shift lever is in reverse position and forward clutch pressure when shift lever is in forward position. Check lube and cooler pressure any time; however, it is not normally a check that is required except when problems indicate a need for checking. Lube pressure should be showing on the gauge at idle speeds above 450 RPM and will reach a maximum of 20 PSI (140 k Pa). Cooler will normally run between 20 and 30 PSI (207 k Pa); however, when cold oil and high speeds are encountered, pressures may exceed 65 PSI (448 k Pa).

A pressure 5 PSI below normal usually indicates leakage in that circuit being tested. Low pressure in all circuits indicates leakage in portion of circuit common to all circuits or a weak pump, stuck regulator valve or restrictions in pump circuit.

PINION CAGE SERVICE

Only well qualified mechanics should consider rebuilding pinion cage and output shaft assemblies.

CAUTION: The oil collector ring must be spun onto carrier after one or more pinions have been removed and replaced. The oil fling must be oil tight around the outside diameter, otherwise the pinions will not receive proper lubrication.

DISASSEMBLY

Use a suitable tool to cut the oil collector ring so that it can be removed from the carrier.

Remove the pinion shaft pin. **CAUTION:** The carrier thrust face will be damaged if the pinion pin is driven out without removing the pinion shaft pin. The shaft pin may be driven all the way into pinion shaft and a punch can be used to break off the end of the pinion shaft pin which is inside of pinion shaft. The pinion shaft pin can then be driven in and will clear the carrier assembly.

Remove the pinion shaft, pinion needles and spacers. Mark gears so they may be replaced in their original location.

INSPECTION

Inspect needles and shafts for pitting, wear and overheating. Discolored parts caused by heat should be replaced. Thrust faces should be smooth. Gear teeth should not be pitted, worn or broken.

ASSEMBLY

Place petrolatum inside the gear to retain needles and spacers during the assembly procedure.

Assemble one spacer and a pinion pin inside of gear.



Assemble a row of needles into each end of gear. **NOTE:** One extra needle may be found in a few early carrier assemblies. Better lubrication will be obtained when the number of needles given on the instruction sheet are used.

Place a spacer over pinion pin and against the needles at each end of gear.

Place a thrust strap over each end of gear, then slide the pinion shaft from the gear and carefully position gear and thrust straps in carrier and slide the pinion shaft into carrier and gear, aligning the pinion shaft pin holes in shaft and carrier. Replace pinion shaft pin and lightly stake in position.

NOTE: A thrust strap replaces and is interchangeable with two thrust washers. There will be extra thrust straps when more than one pinion is replaced since straps are placed in each pinion kit.

Assemble the oil collector ring and spin onto carrier assembly.



NOTE: SERVICE KITS FOR SERVICING CARRIER ASSEMBLIES ARE NO LONGER AVAILABLE
HOWEVER PARTS MAY BE PURCHASED SEPARATELY.

TROUBLE ANALYSIS CHART

| PROBLEM | POSSIBLE CAUSE | CORRECTION |
|--|--|--|
| NO FORWARD OR REVERSE | Low oil level Oil pump not functioning Low oil pressure due to leakage Shift valve incorrectly positioned Broken shafts (Input or output) Cavitation of propeller Broken propeller Pump indexed for opposite rotation | Fill to proper level Repair pump or drive key Find and repair leak Adjust shift linkage Replace broken parts Use slower engine speed or change prop Repair or replace Index pump for correct rotation |
| NO FORWARD | Shift valve incorrectly positioned Forward clutch failed Leakage in clutch circuit Reverse clutch not releasing | Adjust linkage Repair Find and repair leak Repair |
| NO REVERSE | Reverse clutch failed Leakage in reverse clutch circuit Forward clutch not releasing Shift valve incorrectly positioned | Repair Find and repair Repair Adjust linkage |
| NO NEUTRAL | Shift valve incorrectly positioned Reverse clutch not releasing Forward clutch not releasing | Adjust linkage Repair Repair |
| VALVE BUZZ OR NOISE | Air in hydraulic system Low oil level Air leak on suction side of pump Restrictions in oil passages Restricted oil screen Sticky valves | Bubbling will remove air Add oil to full mark Find and repair Remove restrictions Clean and replace Clean valve and add clean oil |
| UNIT OVERHEATS | Cooler oil restricted Cooler oil restricted in lines Cooler water restricted | Reverse flush cooler Reverse flush lines Reverse flush cooler and lines |
| GEARS RATTLE | Flywheel too light Broken, damaged or wrong damper drive assembly Engine idle is rough | Use heavier flywheel Replace with proper damper Tune engine |
| CLICKING NOISE IN REVERSE | Forward and Reverse transmission has a broken gear or chipped tooth | Find and replace damaged gear |
| CLICKING NOISE IN FORWARD & REVERSE | Reduction planetary has a broken gear or chipped tooth | Find and replace damaged gear |

TORQUE SPECIFICATIONS

| PART NO. | APPLICATION | TORQUE LBS. FT. | k Pa |
|---------------|--|--------------------|---------|
| 179857 | BEARING RETAINER & OIL BAFFLE SPACER | 42-50 | 57-68 |
| 4776BB | LOCK BOLT | 42-50 | 57-68 |
| 191641 | REDUCTION SUN GEAR & BEARING RETAINER | 42-50 | 57-68 |
| 179860 | BEARING RETAINER, REAR | 42-50 | 57-68 |
| 4911 | ADAPTER TO CASE | 27-37 | 37-50 |
| 179822 | PUMP TO ADAPTER | 17-22 | 23-30 |
| 179793 | VALVE COVER | 8-11 | 11-15 |
| 115729 | CONTROL LEVER (NUT) | 8-11 | 11-15 |
| 179861 | REDUCTION HOUSING TO TRANSMISSION CASE | 42-50 | 57-68 |
| 4775T | MAIN SHAFT NUT | 160-220 | 217-253 |
| 444592 | DRAIN PLUG | 25-35 | 34-47 |
| 71-2A195 | DIPSTICK ASSEMBLY | 10-15 | 14-22 |
| 10-04-034-002 | DIPSTICK TUBE | 10-40 | 14-54 |

SPECIFICATIONS SUMMARY

| | AS1— | | AS2— | | AS5— | | AS7— | |
|---------------------------|------------|------|------------|------|------------|------|------------|------|
| | 73C | 73CR | 73C | 73CR | 73C | 73CR | 73C | 73CR |
| *INPUT ROTATION | CW | CCW | CW | CCW | CW | CCW | CW | CCW |
| *OUTPUT ROTATION—FORWARD | CW | CCW | CW | CCW | CW | CCW | CCW | CW |
| REDUCTION RATIO—FORWARD | 1.00:1.00 | | 1.50:1.00 | | 3.00:1.00 | | 2.00:1.00 | |
| REDUCTION RATIO—REVERSE | .88:1.00 | | 1.32:1.00 | | 2.64:1.00 | | 1.76:1.00 | |
| TRANSMISSION WEIGHT—DRY | 135 LBS. | | 185 LBS. | | 185 LBS. | | 185 LBS. | |
| OIL CAPACITY—LEVEL | 1.6 QUARTS | | 2 QUARTS | | 2 QUARTS | | 2 QUARTS | |
| OIL CAPACITY—15° INCLINED | 1.5 QUARTS | | 2.2 QUARTS | | 2.2 QUARTS | | 2.2 QUARTS | |

*As viewed from rear of transmission looking forward.

A white name plate will be used on all Model 73C transmissions.

NOTE: Oil capacity does not include oil needed for transmission cooler and external oil lines.

TRANSMISSION FLUID & LUBRICATION REQUIREMENTS

SEE PAGE 7 FOR FLUID RECOMMENDATIONS

IDENTIFICATION OF VELVET DRIVE® IN-LINE MODEL 73C

| TRANS. ASSEMBLY NUMBER (NEW) | TRANS. ASSEMBLY NUMBER (OLD) | INPUT TO OUTPUT SPEED RATIO | | ROTATION (1) | | | PUMP SETTING (2) | PROPELLER REQUIRED (3) | OIL CAPACITY (4) | | | | APPROX. TRANS. WEIGHT | |
|---------------------------------------|---------------------------------------|--------------------------------|---------|----------------|--------------|---------|------------------------|------------------------------|------------------|--------------|--------|--------------|--------------------------|--------|
| | | | | INPUT SHAFT | OUTPUT SHAFT | | | | 15° INCLINED | | LEVEL | | | |
| | | FORWARD | REVERSE | | | FORWARD | | | REVERSE | U.S. QTS. | LITERS | U.S. QTS. | LITERS | POUNDS |
| 10-06-000-004 | AS1-73C | 1:1 | 88:1 | CW | CW | CCW | LH | RH | 1.5 | 1.42 | 1.6 | 1.51 | 135 | 61.2 |
| 10-06-000-005 | AS1-73CR | 1:1 | 88:1 | CCW | CCW | CW | RH | LH | 1.5 | 1.42 | 1.3 | 1.51 | 135 | 61.2 |
| 10-06-000-006 | AS2-73C | 1.6:1 | 1.32:1 | CW | CW | CCW | LH | RH | 2.2 | 2.08 | 2.0 | 1.89 | 185 | 83.9 |
| 10-06-000-007 | AS2-73CR | 1.5:1 | 1.32:1 | CCW | CCW | CW | RH | LH | 2.2 | 2.08 | 2.0 | 1.89 | 185 | 83.9 |
| 10-06-000-008 | AS5-73C | 3:1 | 2.64:1 | CW | CW | CCW | LH | RH | 2.2 | 2.08 | 2.0 | 1.89 | 185 | 83.9 |
| 10-06-000-009 | AS5-73CR | 3:1 | 2.64:1 | CCW | CCW | CW | RH | LH | 2.2 | 2.08 | 2.0 | 1.89 | 185 | 83.9 |
| 10-06-000-010 | AS7-73C (5) | 2:1 | 1.76:1 | CW | CCW | CW | LH | LH | 2.2 | 2.08 | 2.0 | 1.89 | 185 | 83.9 |
| 10-06-000-011 | AS7-73CR (5) | 2:1 | 1.76:1 | CCW | CW | CCW | RH | RH | 2.2 | 2.08 | 2.0 | 1.89 | 185 | 83.9 |

- (1) Input and output shaft rotation is described as clockwise (CW) or counter clockwise (CCW) when the observer is standing behind transmission coupling facing towards front or input shaft end of transmission.
- (2) Pump rotation is described when the observer is standing in front of transmission facing the pump. The arrow located nearest the top of pump face must point in the direction pump will be driven by the input shaft. IT SHOULD BE REALIZED THAT INDEXING THE PUMP FOR OPPOSITE ROTATION DOES NOT CAUSE OUTPUT SHAFT ROTATION TO BE REVERSED, but does permit the transmission to be used behind an opposite rotating engine.

CAUTION: The pump indexing on all assemblies except 2.10:1 reduction units is the only difference between C and CR units. The planetary gears and cage assembly used in C units is different than the one used in CR units in the 2.10:1 reduction units; therefore, indexing the pump for opposite rotation is not permitted on these assemblies. No warranty claims will be allowed for failures caused by improper pump indexing on 2.10:1 reduction units.
- (3) The propeller is described when the observer is standing behind the boat looking forward. A right hand (RH) prop will move the boat forward when rotated clockwise.
- (4) Transmission oil capacity only is given. Additional oil will be required for filling oil cooler and cooler lines.
- (5) All AS7 and AS17 reduction units are counter-rotating, i.e. the output shaft turns opposite to input shaft when the transmission is operated in forward.